

# CLICK Tutorials

# Amazon Alexa Voice Remote (2nd Gen)



## HOME

- Press the HOME button to return to the Fire TV home menu.

## MENU

- To access the menu, press the MENU button.

## SELECT/NAVIGATION

- Press SELECT to access the Guide or other menu options including Shows, Movies, DVR, Settings and Search.
- Use SELECT to navigate through the Menu or Guide.
  - Press up or down to move through the Guide to see programs currently playing. Hold the up or down key to scroll quickly.
  - Press right to move forward in the Guide to view upcoming programs.
  - Press left to go back or access the Replay TV menu.
- When selecting a show in the Guide to watch, press the SELECT button to begin watching. Your viewing options will appear. Press select again to play, record or learn more.
- You can channel surf while watching a program. Once in the program, press up or down to move one channel in the lineup.

## BACK

- Use the BACK button to exit out of the program or menu.


## PLAY/PAUSE

- Utilize the PLAY/PAUSE button to pause a program.

## REWIND and FAST FORWARD

- Use the REWIND and FAST FORWARD buttons to rewind a live program, or to fast forward or rewind a recorded program. Press PLAY to resume playing. To access the DVR, go to the menu then select the 4th icon. You can view your recorded and scheduled programs.

\*Available on Fire Stick 4K remote only. Also, Power button controls TV and Fire Stick on 4K remote.



# CLICK Tutorials

## Amazon Alexa Voice Remote (2nd Gen)

### VOICE COMMANDS

Using the microphone button on your Fire TV Stick you can navigate your TV with your voice. To use this feature, hold down the voice button and ask Alexa a question. She gives helpful information about topics related to your viewing or listening content.

When pressing the microphone button, it is not always necessary to call out Alexa's name. Simply hold the microphone button and state a command.

That said, give some of these commands a try and see how they work:

"Alexa, watch [movie title]"

"Alexa, pause"

"Alexa, fast forward [x] minutes"

"Alexa, rewind [x] seconds."

"Alexa, next/next Episode."

"Alexa, mute."

"Alexa, show me movies with [actor's name]"

"Alexa, play soothing music"

"Alexa, show me popular show on [app]"

"Alexa, go to [channel / network] on [app]"

